



## Notes:

- Option 1: Incorporate into existing landscaping on north side of driveway
- Option 2: squeeze in on south side of driveway above catch basin.

**531 Linden Ln**